



Please note when mounting the 6 pin headers H1 and H2. To ensure that connected modules are at the same height, these headers must be placed higher. Use the 15 pin headers as distance determination and initially solder the headers to the top of the print. For extra strength, a piece of plastic or an old header could be glued between the print and the header. See below:

